

Chapter Four (b): Deleting a Network Time Protocol Server

Summary of Chapter:

- How to delete a Network Time Protocol Server on your NetPilot.

What you need:


- Knowledge of admin user account and valid password for your NetPilot.

Software Revision Required:


- Applicable to software revision 4.1.4 > NetPilots

Deleting a Network Time Protocol Server:

- Log on to the NetPilot as shown in Chapter One (b).
- Select the 'Maintenance' button on the left-hand side of the screen and then the 'Advanced' button at the top of the screen. In the list of links select the 'Time Servers' link: (both buttons and the link are highlighted in the screen below)



- Once you have selected the link you will be presented with the screen below. Highlight the time server you wish to delete from the list provided and select the 'Delete' button, as highlighted below:



- Select 'OK' and 'OK' again to confirm.