

Chapter Nine (a): Entering a DNS Server

Summary of Chapter:

- How to enter a DNS Server on your Pilot.

What you need:

- Knowledge of Admin user account and valid password for your Pilot.
- The IP address of the DNS Server/s.

Software Revision Required:

- Applicable to software revision 5.2.0 > Net/CachePilots

(Net/CachePilot will be referred to as 'Pilot'. All image examples are of a NetPilot.)



The Pilot by default will use the Internet root name-servers automatically.


Entering a DNS Server:

- Log on to the Pilot as shown in Chapter One (b).
- From the left-hand side of the screen, select 'Time and date' and then 'Time servers'. (All links are highlighted below).



- You will be presented with the screen shown above, select the 'Add' button as highlighted.

- You will be presented with the screen below. Enter the IP address of the DNS Server you would like to be queried first.



- Once you have entered the IP address, select 'OK' and then 'OK' again to confirm.